KIT DE DÉTARTRAGE DESCALING KIT • ONTKALKINGS KIT





















PL LT RU PT AR CN







SAFETY INSTRUCTIONS

DANGER: contains citric acid. CORROSIVE



SPECIAL DESCALER PRODUCT

Descaler product for * espresso machine 1235 PRESSO



To use it, please read your machine's user manual carefully.

- · Causes burns to the skin and serious lesions to the eyes. Avoid all contact with the skin and eves.
- Keep out of children's reach.
- Wear protective gloves, eye protectors and protective clothing.
- · Store in a closed container.
- IN THE EVENT OF CONTACT WITH THE EYES: Rinse carefully with water for several minutes. Remove the victim's contact lenses if they are wearing any and if they may be removed easily. Keep rinsing.
- IN THE EVENT OF CONTACT WITH THE SKIN (or hair): remove contaminated clothing immediately. Rinse the skin with water / shower.
- IF SWALLOWED: Rinse mouth. DO NOT make the person vomit.
- Call a POISON CONTROL CENTRE or a doctor immediately. European number 112.
- The machine's warranty is guaranteed only if the machine is descaled regularly (every 6 months).
- For your safety, make sure that you follow the instructions in this user manual.

LIMESCALE REMOVAL DETAILS

- For NéOh Expresso and Xpress'OH, please proceed as stated below:
- Fill the water tank with 0.5 liter of water.
- 2. Add the full bottle of descaling liquid to the water.
- 3. Turn the machine ON. Wait for the machine to be ready for brewing (heating phase completed - no LED flashing).
- 4. Remove the Drip Tray and place a recipient under the coffee spout.
- 5. Put the descaling rubber strip in position.







- 6. Lower the handle (no. 2)
- Press the Large coffee (no. 5) button and let it run until it stops automatically.
- 8. Repeat these operations till water tank is empty.
- Once the water tank is empty, turn the machine OFF, remove the water tank from the machine.
- 10. Rinse thoroughly the water tank.
- 11. Fill the Water Tank completely with water.
- Replace the water tank on the machine, and turn it ON. Wait for the machine to be ready for brewing (heating completed – no LED flashing).
- 13. Repeat Step 7 untill water runs clear.